
Whidden Gunworks Universal Click Adjustable Lock Ring For CO-AX Press's



Please take a moment to familiarize yourself with the lock ring adjustment screws.

#1 Screw: Tighten here to secure lock ring to Die body.

#2 Screw: Tighten here to secure the outer lock ring. (after final adjustment)

#3 This is a rubber spring-no adjustment is necessary.

Setup:

- 1. Lightly loosen screw #1. Install onto die body with adjustment screws facing down.
- 2. Tighten screw #1. WARNING: Screw does not require much torque.
- 3. Loosen screw #2 approx. ½ turn
- 4. Adjust the inner lock ring to be all the way up in the outer lock ring. Then back inner lock ring half way down (Approx. 14 clicks)
- 5. Loosen # 1 Screw and make coarse adjustment on die, then tighten. (do not over torque)
- 6. Make your final adjustments by turning the inner lock ring upwards or downwards. When finished tighten #2 Screw. You can expect only the outer lock ring portion to contact the press.

