


We Manufacture Confidence®



**LIGHTNING BOW**<sup>TM</sup> FOR THE IWI TAVOR® Installation Instructions

## **READ THIS FIRST**

Firearm safety is **YOUR** responsibility. You must memorize and put into practice the 4 Rules of Firearm Safety:

- 1. ASSUME EVERY WEAPON IS LOADED.
- 2. KEEP YOUR FINGER OFF THE TRIGGER UNTIL YOU ARE READY TO SHOOT.
- 3. DO NOT LET THE MUZZLE POINT AT ANYTHING YOU ARE NOT WILLING TO DESTROY.
- 4. KNOW YOUR TARGET AND WHAT IS BEYOND.

The Geissele Lightning Bow™ is an advanced replacement trigger bow for the IWI Tavor® rifle. Made from nitrided alloy steel, the Lightning Bow's hybrid flat face/curved bow spreads the pressure from the trigger squeeze over a larger area, giving the shooter unprecedented trigger control.

The Lightning Bow also removes the inherent slack and looseness from the Tavor's long trigger bar. This tightens up the trigger pull and when combined with the Geissele Super Sabra trigger pack will give the Tavor the best trigger pull of any bullpup rifle.

*Geissele Automatics recommends installation by a certified gunsmith only* 

## INSTALLATION INSTRUCTIONS

- 1. Follow the IWI armorer instructions for removing the barrel assembly and the stock trigger bow. Also remove the trigger pack from the rifle.
- Remove the retainer wire (Item 2) for the trigger spring from the Lightning Bow (Item 1).
  WARNING: The trigger pin will <u>not</u> push the retainer wire out of the way if an attempt is made to insert the trigger pin while the retainer wire is installed. The retainer wire MUST be removed before pin installation or removal and only installed once the trigger pin is in place.
- 3. Install the Lightning Bow being careful not to excessively bend the trigger bar when inserting the round boss into the bar.
- 4. Install the trigger pin and line up the groove in the trigger pin with the intersecting hole for the retainer wire.
- 5. Install the retainer wire using the 3-48 x1/4" (Item 3) screw to secure the retainer wire to the Lightning Bow.
- 6. At this time the Lightning Bow must be checked for rubbing in the housing slot. Push the trigger pin back and forth until the Lightning bow swings freely. It is recommended to push the pin to one side to get the trigger to rub, then push back the other way in small increments until the bow swings freely. The interference fit of the plastic housing to the trigger pin will hold the pin and bow in place.

**NOTE:** If the trigger will not swing freely, check for interference areas where the plastic receiver is touching the trigger. Areas to look for where rubbing may occur are listed on the attached drawing.

- 7. Re-install the trigger pack.
- 8. The slack adjustment screw (Item 4) can now be turned in so that any slack present in the trigger bar can be removed. The polymer compound on the slack adjustment screw will keep the screw in place. Be careful dry firing the trigger without the bolt carrier in place.
- After this process is complete, it is very important to check the safety for proper operation. If the safety can not be engaged, the adjustment screw has to be backed off slightly.
- 10. Once the slack is removed from the trigger, the rifle can now be re-assembled according to the IWI armorer instructions.
- 11. After re-assembly, recheck safety function and test fire the rifle using just two rounds in the magazine to verify proper function.

Thank You For Your Purchase. Contact Geissele Automatics with any questions.

GEISSELE AUTOMATICS • 800 NORTH WALES RD • NORTH WALES, PA 19454 TEL: 610-272-2060 | FAX: 610-272-2069 E-MAIL: INFO@GEISSELE.COM | WEB: WWW.GEISSELE.COM

GEISSELE AUTOMATICS LIGHTNING BOW INSTRUCTIONS VERSION 2 - 03/17/15

