

## **Includes:**

- Steel Frame and Upright Supports (8 Steel Pieces)
- 9-Socket Head Cap Screws (1 Extra)
- 9-Thumb Screws
- 1-Hex Wrench



## **Assembly Instructions:**

1. Thread the (8) socket head cap screws into the side of the uprights (4 on each side):





2. Attach the steel base to the outside of the upright frame using the thumb screws:



3. Once each side is assembled, simply connect the middle sections at the desired width using the remaining thumb screws:





21"



24"

