

JPTR MIL-STD-1913 Modular Rail

Parts included:

JPTR-L

- Four-inch rail piece
- Three-hole backer plate
- Three (3) 10-32 x 1/2" flat socket cap screws

JPTR-S

- Two-inch rail piece
- Two-hole backer plate
- Two (2) 10-32 x 1/2" flat socket cap screws

Installation Instructions

CAUTION: REMOVE MAGAZINE AND VISUALLY CHECK CHAMBER TO MAKE SURE THAT FIREARM IS UNLOADED.

The JP Modular Rail adapter system allows for complete flexibility as far as placement on the outside of the tube. One or several can be mounted for a variety of applications while still keeping the overall weight of the forend to a minimum. Our rails specially designed for the JP series of free float tubes. However, they can be used to provide a rail interface on most other free float tubes.

For use on JP hand guards, place the backer plate in the desired slot on the inside of the tube. It may help to use a small hex key or knife blade inserted though the adjacent slots in the JP tube to keep the slot piece in place while you inert the screw(s). The backer plate and rail on the JPTR-L have multiple holes for flexibility. Only one of the 10-32 flat head screws is actually needed to lock the rail into position.

We also carry the JPoint microelectronic reflex sight and M3 Tactical Illuminators for use on your rail.

THANKS FOR YOUR BUSINESS!

Visit us at www.jprifles.com

Rev. 02.11

P.O. Box 378, Hugo, MN 55038 · Voice: 651-426-9196 · Fax: 651-426-2472