

PIRANTA

Removing The Blade


- Grip top of blade with forceps away from cutting edge.
- Lift heel of the blade at point "A" with the tip of your index finger, being careful to avoid cutting edge.




- Slide blade off handle with forceps pulling blade away from handle.

Blade Remover (For Piranta Only)


Step 1
Open remover and place blade in slot.



Step 2
Close remover around blade.




Step 3
Squeeze remover with right hand where it says PRESS and pull knife at the same time.




Attaching The Blade

- Peel open foil so about half of blade is exposed. Grip blade with forceps or needle-nose pliers on top, away from cutting edge. (1)



- Hold knife handle with blade fitment pointing up. (1)
- Place blade over tip of fitment and engage blade in the slots. (2)




- Slide blade down slots until it clicks into position. If you don't feel it click at base, blade is not completely secure. Start over.

BARACUTA

Removing The Blade


- Grip top of blade with forceps away from cutting edge.
- Lift heel of the blade at point "A" with the tip of your index finger, being careful to avoid cutting edge.




- Slide blade off handle with forceps pulling blade away from handle.

Attaching The Blade

- Grip blade with forceps or needle-nose pliers on top, away from cutting edge. (1)



- Hold knife handle with blade fitment pointing up. (1)
- Place blade over tip of fitment and engage blade in the slots. (2)




- Slide blade down slots until it clicks into position. If you don't feel it click at base, blade is not completely secure. Start over.

TALON

Removing The Blade


Press down on the Quik-Change II blade release button and pull the blade with the opposite hand to remove.



Quik-Change II button

Attaching The Blade

Insert the blade into the fitment, press down on the Quik-Change II button and slide the blade into place. Once the blade is in the handle, release the Quik-Change II button and the blade will be locked into place.



Quik-Change II button


REDI

Removing The Blade

1. Open knife and make sure the blade is locked into place.



2. Press the button on the fitment and slide the REDI-Lock system forward.



3. Blade should now be loose. Slightly lift up the back of the blade and pull forward.



Attaching The Blade

1. To put blade on, reverse these same steps.

