# IA ASCENT™ SIZING

SM М XL 2XL 3XL 4XL 5XL **PARKA CHEST** 40"- 42" 43"- 46" 47"- 50" 51"- 54" 55"- 58" 59"- 62" 63"- 66" 67"- 70" HEM 41"- 43" 44"- 47" 48"- 51" 52"- 55" | 56"- 59" | 60"- 63" | 64"- 67" | 68"- 71" **SLEEVE** 37" 38" 38" 38" 39" 39" 39" 36" **BIB** WAIST 32"- 35" 36"- 39" 40"- 43" 44"- 47" | 48"- 51" | 52"- 55" | 56"- 59" |


### NOTE:

For optimum fit, measure while wearing a typical garment such as a sweatshirt.

# ICEARMOR"

INSEAM | 26"- 32" | 26"- 32" | 27"- 33.5" | 27"- 33.5" | 27"- 33.5" | 27"- 33.5" | 27"- 33.5" | 27"- 33.5"





### CHEST

Measure around chest 1" below armpit.

### SLEEVE LENGTH

Measure from center spine across the shoulder down the arm past wrist.

### HEM

The hem is the lower opening in the parka below the stomach.

## WAIST

Measure 1" above the belt line.

# INSEAM

Measure from crotch to inside ankle.